


COOKTOP PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



30" GAS FREESTANDING
SELF CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1	9762998	Literature Parts Installation Instructions Anti-Tip Template English/Spanish English/French Owners Manual Tech Sheet Safer Cooking Tips
2	3191904	Cap, Burner Left Front Black
	3191905	Grey
	8273345	Espresso R. Front, L. Rear
	3191901	Black
	3191903	Grey
	8273344	Espresso Right Rear
	3191898	Black
	3191899	Grey
	8273343	Espresso


Illus. No.	Part No.	DESCRIPTION
3	4455981	Burner Left Front
	4455980	R. Front, L. Rear
	4455979	Right Rear
4	8272251	Cooktop White
	8272743	Biscuit
	8272253	Black
5	8523855	Panel, Manifold Black
	8523854	White
	8523856	Biscuit

Illus. No.	Part No.	DESCRIPTION
6	8273103	Knob, Control (3) Black
	8273104	White
	8273106	Biscuit
7	8273111	Knob, Powerburner Black
	8273112	White
	8273114	Biscuit
8	8522851	Grate, Burner (4) Black
	8522850	Grey
	8522853	Espresso
9	3400701	Screw
10	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1		Endcap, Left Hand
	W10009080	Black
	W10009040	White
	W10009060	Biscuit
		Endcap, Right Hand
	W10009090	Black
	W10009050	White
	W10009070	Biscuit


Illus. No.	Part No.	DESCRIPTION
2		Panel, Control
	9762093	Black
	9762091	White
	9762092	Biscuit
	9762094	Silver for Stnlss
3	9758080	Module, Spark
4	9762095	Brkt-Mntg, Console
5	8523412	Bracket, Support
6	9756301	Cover, Upper
7	8053910	Shield, Heat
8	8273132	Cover, Lower

Illus. No.	Part No.	DESCRIPTION
9	3196169	Screw
10		Control, Range
	W10114384	Black
	W10114383	White
	W10114385	Biscuit
11	3196178	Screw
12	9757609	Badge
13	9762726	Brkt-Mntg, DSI
14	8273564	Clip
15	9762078	Brkt, Mntg EOC
16	8053505	Heat-Shield, Lower

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)


Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
2		Burner Base
	8273700	Large (3)
	8273701	Small (1)
3		Tubing, Burner W/Orifice
	8273693	Left Front
	8273698	Left Rear
	8273695	Right Front
	8273697	Right Rear
4	8523402	Tubing (Manifold to Regulator)
5	8523406	Harness, Igniter (W/Switches)
6	8523793	Electrode (4)
7	9762230	Pipe, Manifold
8		Valve
	9757218	LF – RF – LR
	8273004	Right Rear
9	8273060	Nut (4)
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	8053970	Spreader, Flame (Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16		Igniter
	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler Fitting To Valve)
18	3186489	Fitting, Broiler
19	8272403	Cover, Igniter
20		Orifice, Burner
	8273064	Left Front
	8273065	Right Front
	8273066	Left Rear
	8273067	Right Rear
21	8053262	Spreader, Flame (Broiler)
22	3196265	Screw
23	3196176	Screw
24	3196385	Screw
25	3400016	Screw

Following Parts Not Illustrated

8523420 Spuds, LP Gas
(Kit of 4)

CHASSIS PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	W10012240	Flue Box	16	9758701	Spacer, Door	34	3196152	Screw
2	8272747	Shield, Flue	17	9757098	Back, Main	35		Screw
3	8273036	Burner Box	18	8522416	Seal, Oven		3196166	White
4		Panel, Side (2)	19	8053971	Brace, Main Back		8281194	Biscuit
	8053830	White-Textured	20		Retainer, Insul.		3196168	Black
	8272519	Biscuit-Textured		9761449	Left Hand	36	W10031780	Screw
	8053832	Black-Textured		9761448	Right Hand	37	3196179	Screw
5	8523249	Brkt, Manifold Mtg	21	3196576	Clip, Panel (6)	38	3196177	Screw
6		Frame, Front (Not Serviced)	22	9757891	Cord, Power	39	3196168	Screw
7	3196037	Foot, Front (2)	23	9760407	Brkt – Hinge	40	9757239	Rod – Door Switch, Rear Mount
8	W10058460	Foot, Rear (2)	24	9757262	SWITCH, DOOR	41	3196560	Screw
9	3195097	Bottom, Oven	25	3196701	Light Socket Assy			
10	8273902	Sensor, Oven	26	311255	Bulb, Oven Light			
11	8053967	Baffle, Burner	27	9761013	Latch, Door			
12	8053969	Shield, Heat	28	W10078370	Rod, Latch			
13	8053968	Shield, Lower	29	W10107820	Latch-Mtr			
14	9760314	Rail, Base (2)	30	9759785	Glide, Drawer			
15	W10008830	Seal, Oven Flange	31	9761490	Insulation			
			32	9761512	Clip, Mounting			
			33	3196178	Screw			

INSULATION

8524099 Insulation, Wrap
8272614 Insulation, Back
8272613 Insulation, Vent

DOOR PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS


For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Trim, Top	9	9761357	Retainer, Insul.	13	3196160	Screw
	9762391	Black	10		Hinge, Door	14	3196165	Screw
	9761975	White		9761493	Wht,Blk,Bsct,US	15	3196025	Clip, Door Glass
	9761976	Biscuit		9761496	Stainless Model	16	3196794	Bracket, Window(2)
	9762394	Stainless Steel	11		Glass, Outer Door	17		Trim, Bottom
	W10067560	Universal Silver		W10075990	Black		8523177	Black
2	3196164	Screw		W10075980	White		8523175	White
3		Handle, Door		W10076000	Biscuit		8523178	Biscuit
	9761983	Black		9756435	Stnls & Univ Slvr		8523180	Stainless Model
	9761982	White	12		Trim, Door Side		W10067550	Universal Silver
	9761984	Biscuit			Left Hand	18	9761517	Clip, Door Mntg
	9761985	Universal Silver		8523171	Black	19	W10031780	Screw
4	9761344	Liner, Door		8523172	White	20	W10113759	Strap, Door
5	W10031790	Screw		8523173	Biscuit			
6	9758162	Glass, Inner (2)		W10113926	Universal Silver			
7	3186289	Frame, Glass			Right Hand			
8	8272618	Insulation, Door		8523165	Black			
				8523166	White			
				8523167	Biscuit			
				W10113925	Universal Silver			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER & BROILER PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)



Illus. No.	Part No.	DESCRIPTION
1	3195710	Rack, Oven (2)
2	9761031	Drawer, Storage
3	3196817	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196815	Almond
	3196813	Black
5		Panel, Drawer Frnt
	W10022090	White
	W10022110	Biscuit
	W10022100	Black
6	8053334	Spacer, Glide
7	9755797	Panel, Stnls & US
8	3196168	Screw
9		Handle, Door
	9757219	Stainless Model
	9762251	Universal Silver
11	W10031790	Screw, Universal Silver and Stainless Steel Models

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: SF362LXTB0, SF362LXTQ0, SF362LXTT0, SF362LXTS0, SF362LXTY0
(Black) (Designer White) (Designer Biscuit)(Stainless Steel) (Universal Silver)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

Parts Not Illustrated and
Optional Parts (Not Included)

SPLICING WIRES--25FT. LENGTH

242828	Wire, Black	12 Ga. 150° c
242821	Wire, Blue	14 Ga. 150°c
242822	Wire, Brown	14 Ga. 150°c
242830	Wire, Brown	14 Ga. 200°c
242823	Wire, Green	14 Ga. 150°c
242824	Wire, Orange	14 Ga. 150°c
242825	Wire, Red	14 Ga. 150°c
242831	Wire, Red	14 Ga. 200°c

REFINISHING MATERIAL

242756	Touch-Up	Self-Clean(1/2 Pt)
261582	Grease	

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

INSULATION

261514	Insulation,	Fiberglass (1-1/2" x 24" x 120")
240132	Insulation,	Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017	White	
4392899	Biscuit	
511873	White Porcelain	(2 Oz.)

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White	
4392901	Biscuit	
285006	Superior Black	
206922	Primer (White)	

PAINT, BULK (1 qt.)

799344	White (Uncut)	
4392900	Biscuit (Uncut)	

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

ACCESSORY PARTS

241430	Foil, Aluminum	Oven (18" x 25')
4396923	Pan - Broiler	

ANTI-TIP KIT

W10017440	Anti-Tip Kit	
-----------	--------------	--

WIRING HARNESS PARTS

9762433	Harness, Main	(EOC Pyro)
8524207	Harness, Wire	Bake/Broil
8523599	Harness, Wire	(Cooktop Spark)
W10045060	Harness, Wire	(Ground)
3196896	Clip, Wire	
3400964	Clip, Wire	
313438	Clip, Harness	
3196173	Screw	
3196696	Clip, Harness	
3196174	Screw-Grnd Harns	